

Melt-blown fabric

REF No. : WLFMB

Features: With good filtering, shielding, heat insulation and oil absorption, corona electret gives cloth strong electrostatic stability, comprehensive production efficiency is high. The water electret makes the cloth surface permeability is good, the electret is stable, the retention time is long, the adsorption is strong; Under the condition of low resistance, better filtration effect can be achieved.

Application: Medical and health cloth, such as operating clothes, protective clothing, disinfectant bag cloth, mask, diaper, women's sanitary napkin; Filter materials, insulation materials, cement bags, covering cloth and other industrial clothing; Crop protection cloth, seedling cloth, irrigation cloth, heat preservation curtain and other agricultural cloth.

Color: White

Specifications: Weight and width are customizable (width < 1.6M), commonly used specifications are mask cloth specifications: 25g*175mm, 30g*175mm, 25g*220mm, 25g*260mm, 30g*220mm, 40g*220mm, 40g*260mm.



| REF. | Weight/gsm | Standard | Filter efficiency | Size/mm | Package |
|----------------|------------|--|--------------------|---------|-------------|
| WLFMB25CN1755 | 25 | YY 0469-2011 YY/T 0969-2013 Type I | BFE≥95% PEF≥30% | 175 | 5 roll/bags |
| WLFMB25ACN1755 | 25 | Type II | BFE≥98% | 175 | 5 roll/bags |
| WLFMB30CN1755 | 30 | Type IIR | BFE≥98% | 175 | 5 roll/bags |
| WLFMB25BCN1755 | 25 | ASTM Level 1 | BFE≥95% PFE≥95% | 175 | 5 roll/bags |
| WLFMB30ACN1755 | 30 | ASTM Level 2 ASTM Level 3 | BFE≥98% PFE≥98% | 175 | 5 roll/bags |
| WLFMB25CN2204 | 25 | N95 KN95 GB 19083-2010 | PFE≥95% salt | 220 | 4 roll/bags |
| WLFMB25CN2603 | 25 | N95 KN95 GB 19083-2010 | PFE≥95% salt | 260 | 3 roll/bags |
| WLFMB40CN2204 | 40 | FFP2 R95 KP95 | PFE≥95% salt & oil | 220 | 4 roll/bags |
| WLFMB40CN2603 | 40 | FFP2 R95 KP95 | PFE≥95% salt & oil | 260 | 3 roll/bags |
| WLFMB30CN2204 | 30 | N99 | PFE≥99% salt | 220 | 4 roll/bags |
| WLFMB30ACN2204 | 30 | FFP3 R99 | PFE≥99% salt & oil | 220 | 4 roll/bags |



Mask Cloth

Specification:

| Weight | Size |
|--------|-------|
| 25gsm | 175mm |
| 30gsm | 175mm |
| 25gsm | 220mm |
| 25gsm | 260mm |
| 30gsm | 220mm |
| 40gsm | 220mm |
| 40gsm | 260mm |

Color: ○

Package: 5 roll/bags
4 roll/bags
3 roll/bags