



[Type 5/6 Flame Retardant SMS Coverall]

EN ISO 15025

Vertical Flammability Test used in **EN 14116**.

The **EN ISO 15025** test used in **EN 14116** applies a small flame to the centre of a sample of the garment fabric suspended vertically for 10 seconds.

Fabric is classified according to one of three "index's" according to recorded performance.

Our **EN 14116** Secondary FR disposable fabrics meet the Index 1 requirements.

Index 1

- No flame or melting to reach upper or outer edge
- No flaming or molten debris
- Afterglow < 2 seconds

Index 2

- Satisfying Index 1
- No hole formation > 5mm

Index 3

- Satisfying Index 2
- Afterflame < 2 seconds



REF	Color	Size
WLO3003FR	White	S-4XL
WLO3003FRB	Blue	S-4XL



Type 5
 EN ISO 13982-1/04+A1/10
 Type 6
 EN 13034/05+A1/09



EN 1149-5:2018



EN ISO 14116:2015